

रि

Operation

V1.0









EN

Basic Functions


















Basic Functions

Button Functionality

	 Start Recording
	 End Recording
	Power On (2s) Power Off (2s) Select Menu Item (Click) Mark as Important (Click whilst recording)
	SOS Mode (Streaming)
	Open Menu Navigate Menu Stealth Mode (2s)

LED light

Operation
 Powered on
 Recording
 Pre-Recording
 10s Trigger Mode
 Connecting
 Connected
Charging
 Charging
 Fully charged







DEMS 360
 Uploading
 Deleting files
Not booked out:
 Charging
 Charged
Booked out:
 Charging
 Charged
 Updating Firmware







Menu Navigation



Menu Navigation








Button Functionality

	Open Menu Navigate Menu
	Select Menu Item (Click)
	Back
	Settings
	Connection Menu
	Audio Mute

	Stealth Mode
	Wi-Fi Network Menu
	Streaming
	Wireless Upload
	QR Code Scanning Mode
	WPS Connection

The button icon in focus has red outline.
Active Feature's Icons are solid white.

Screen Data

	Wi-Fi Signal Strength
	Bluetooth Disabled / Enabled
	Video Streaming Enabled, but not active
	Video Streaming Active
	Battery Charge
	Current Time
	Current Date

Battery Safety

Reveal's body cameras use lithium-Ion batteries which are common in most portable devices such as radios and mobile phones. Reveal's cameras are safety tested with the appropriate certification.

Damage to a lithium-Ion battery can cause excessive heat build-up often associated by an audible "hissing" sound, smoke and, in extreme cases, combustion. The R1 casing provides a significant degree of battery protection, however, if the case becomes punctured or crushed by excessive forces, then there is a risk of battery damage. Therefore, we recommend that the user of cameras performs a risk assessment as to the role of the wearer and likelihood of excessive trauma to the camera.

If a camera becomes excessively hot or emits any unusual sounds or smoke then:

- Immediately detach the camera and place in a safe area.
- Do not charge the camera.
- Contact Reveal Support.

Storage

Store in dry place, away from direct sunlight and sources of heat, at a temperature between -10°C and 45°C (14°F to 113°F).

Lithium-ion battery discharge naturally over extended periods of time and if not charged for prolonged periods of time, may deteriorate resulting in reduced performance and failure.

If your R1 camera is kept in long-term storage it should be charged to at least 50% of full charge every six months. Your warranty may be invalidated if you fail to recharge your battery regularly or to follow other instructions for the storage, installation, commissioning, use or maintenance of the camera.